

A vertical blue bar with rounded ends, positioned to the left of the main text.

Subscriber terminal  
**NTU-MD500P**

User Manual  
Firmware version 2.4.7

## Contents

1	List of changes.....	4
2	Introduction .....	5
3	Product Description .....	6
3.1	Purpose .....	6
3.2	Overview .....	6
3.3	Technical specifications.....	7
3.4	Design.....	9
3.4.1	Front panel layout .....	9
3.4.2	Side and back panels of the device .....	10
3.5	Light indication.....	11
3.6	Delivery package .....	11
4	Installing and connecting NTU-MD500P .....	12
4.1	Operating conditions and installation procedure.....	12
4.1.1	Safety requirements .....	12
4.1.2	Installation procedure.....	12
4.2	Connecting the device .....	14
5	Device architecture .....	15
6	Configuring the device via web interface. Admin access. ....	16
6.1	Status menu. Device information .....	18
6.1.1	Device submenu. General information on the device.....	18
6.1.2	IPv6 Status submenu. IPv6 System Information .....	19
6.1.3	PON submenu. Optical module status .....	20
6.1.4	LAN submenu. Information on the status of LAN interface.....	21
6.2	LAN menu. Configuring LAN interface .....	21
6.3	WAN menu. Configuring WAN interface.....	22
6.3.1	PON WAN submenu.....	22
6.3.2	VPN submenu .....	23
6.4	Services menu. Configuring services .....	26
6.4.1	DHCP Settings submenu. Configuring DHCP .....	26
6.4.2	DNS submenu .....	27
6.4.3	Firewall submenu. Configuring the firewall.....	28
6.4.4	UPnP submenu. Automatic configuration of network devices.....	33
6.4.5	RIP submenu. Configuring dynamic routing .....	34
6.5	Advance menu. Advanced settings .....	35
6.5.1	ARP Table submenu. Viewing the ARP protocol cache .....	35

6.5.2	Bridging submenu. Configuring Bridging parameters .....	35
6.5.3	Routing submenu. Configuring routing .....	36
6.5.4	Interface grouping submenu. Combining interfaces into groups.....	37
6.5.5	IP QoS submenu. Configuring the quality of services provided (QoS).....	37
6.5.6	PoE Settings submenu. Configuring PoE ports .....	41
6.5.7	Link mode submenu. Configuring LAN ports.....	42
6.5.8	Others submenu. Additional settings .....	42
6.5.9	IPv6 submenu. Configuring IPv6 protocol.....	43
6.6	Diagnostics menu .....	50
6.6.1	Ping submenu. Checking the availability of network devices .....	50
6.6.2	Traceroute submenu. Network diagnostics.....	50
6.6.3	System Log submenu. Logging system events .....	50
6.7	Admin menu .....	51
6.7.1	Settings submenu. Restore and reset settings.....	51
6.7.2	GPON Setting submenu. Configuring access to GPON.....	52
6.7.3	Commit/Reboot submenu. Saving changes and restarting the device.....	53
6.7.4	Logout submenu. Log out the account .....	53
6.7.5	Password submenu. Setting up access control (setting passwords).....	54
6.7.6	Firmware upgrade submenu. Software Update .....	54
6.7.7	Remote Access submenu. Configuring remote access rules.....	55
6.7.8	Time zone submenu. Configuring system time .....	55
6.7.9	TR-069 submenu. Configuring TR-069 .....	56
6.8	Statistics menu. Information about the traffic on the device ports.....	57
6.8.1	Interface submenu. Information about counters and errors.....	57
6.8.2	PON submenu .....	57

## 1 List of changes

<b>Document version</b>	<b>Software</b>	<b>Release date</b>	<b>Changes</b>
Version 1.1	2.4.7	09.2022	Second publication
Version 1.0	1.0.1	04.2021	First publication

## 2 Introduction

GPON network belongs to one of the varieties of passive optical PON networks. This is one of the most modern and effective solutions for "last mile", which allows significant savings on cable infrastructure and provides data transmission speed of up to 2.5 Gbps downlink and 1.25 Gbps uplink. The use of GPON-based solutions in access networks makes it possible to provide end users with new IP services together with traditional ones.

The main advantage of GPON is the use of a single line terminal (OLT) for multiple subscriber devices (ONT). OLT is a converter of Gigabit Ethernet and GPON interfaces, which serves to connect the PON network with higher-level data transmission networks. The ONT device is designed to connect customers' equipment to broadband access services. It can be used in residential areas and business centers.

The user manual describes the purpose, main technical specifications, configuration rules and monitoring of the optical network terminal NTU-MD500P.

### Notes and Warnings

 The tips contain important information or recommendations for using and configuring the device.

 The notes contain additional information on using and configuring the device.

 Warnings inform of the situations when actions may harm the device or a user, lead to fault operation of the device or data loss.

## 3 Product Description

### 3.1 Purpose

NTU-MD500P is an optical network terminal that has four 10/100/1000BASE-T ports with support for IEEE 802.3at PoE+ technology. NTU-MD500P provides up to 30 W of power on 10/100/1000BASE-T ports with a PoE power budget of 65 W.

Support for PoE technology allows NTU-MD500P to supply power via UTP cable to IP phones, wireless access points, IP cameras and other PoE-enabled devices.

The advantage of GPON technology is the optimum use of bandwidth. This technology is the next step to provide new high-speed internet connection at home and in offices. Designed to deploy a network inside a home or building, NTU-MD500P provides reliable connection with high bandwidth over long distances for users living and working in remote apartment buildings and business centers.

### 3.2 Overview

***NTU-MD500P has the following interfaces:***

- 1 PON SC/APC port for connecting to the operator's network (WAN);
- 4 Ethernet RJ-45 LAN ports (10/100/1000BASE-T) for connecting network devices (LAN).

***NTU-MD500P supports the following functions:***

- *PoE management and monitoring via OMCI:*
  - ONU-G::PSE overload yellow;
  - ONU-G::PSE overload red;
  - Physical path termination point Ethernet UNI::Power control;
  - Power over Ethernet control::Operational state;
  - Power over Ethernet control::Power detection status;
  - Power over Ethernet control::Power classification status;
  - Power over Ethernet control::Current Power Consumption;
  - Power over Ethernet control::AVC;
  - Power over Ethernet control::Power priority.
- *Network functions:*
  - support for TR-069;
  - operation in "bridge" or "router" mode;
  - PPPoE (auto, PAP-, CHAP-, MSCHAP-authorization);
  - IPoE (DHCP client and static);
  - DNS (Domain Name System);
  - DynDNS (Dynamic DNS);
  - UPnP (Universal Plug and Play);
  - VPN in L2TP mode;
  - L2TP over IPsec;
  - IPsec (transport mode);
  - NAT (Network Address Translation);
  - NTP (Network Time Protocol);
  - QoS (quality of service mechanisms);
  - IGMP-snooping;
  - IGMP proxy;
  - VLAN according to IEEE 802.1Q.
- *Firmware update via TR-069, OMCI, HTTP, TFTP;*
- *Remote monitoring and configuration:*
  - SNMP-agent OLT;
  - CLI OLT.

The figure below shows the use case of NTU-MD500P.




Figure 1 – NTU-MD500P use case

### 3.3 Technical specifications

The main technical parameters of the terminal are given in [Table 1](#):

Table 1 – Technical specifications

Parameters of LAN Ethernet interfaces	
Number of interfaces	4
Electrical connector	RJ-45
Data rate	Auto-detection, 10/100/1000 Mbps, duplex/half duplex
Supported standards	IEEE 802.3i 10BASE-T Ethernet IEEE 802.3u 100BASE-TX Fast Ethernet IEEE 802.3ab 1000BASE-T Gigabit Ethernet IEEE 802.3x Flow Control IEEE 802.3 NWay auto-negotiation IEEE 802.3af IEEE 802.3at
PON interface parameters	
Number of interfaces	1
Supported standards	ITU-T G.984.x Gigabit-capable passive optical networks (GPON) ITU-T G.988 ONU management and control interface (OMCI) specification IEEE 802.1Q Tagged VLAN IEEE 802.1P Priority Queues IEEE 802.1D Spanning Tree Protocol
Connector type	SC/APC corresponds to ITU-T G.984.2, ITU-T G.984.5 Filter, FSAN Class B+, SFF-8472
Transmission medium	Fiber optic cable SMF – 9/125, G.652
Split ratio	Up to 1:128

Maximum distance	20 km
Transmitter:	1310 nm
• Upstream data rate	1244 Mbps
• Transmitter power	From +0.5 dBm to +5 dBm
• Spectrum width (RMS)	1 nm
Receiver:	1490 nm
• Downstream data rate	2488 Mbps
• Receiver sensitivity	From -8 to -28, BER $\leq$ 1.0x10 <sup>-10</sup>
Optical overload of the receiver	-8 dBm
<b>Management</b>	
Local management	Web, CLI
Remote control	TR-069, OMCI
Firmware update	OMCI, TR-069, HTTP, TFTP
Access restriction	By password
<b>General parameters</b>	
Power supply	110-250 V AC, 50-60 Hz
Maximum power consumption	80 W
Operating temperature range	From 0 to +40 °C
Relative humidity	No more than 80%
Dimensions (W × H × D)	267 × 44 × 178 mm
Form factor	19", size 1U
Weight	1.56 kg

### 3.4 Design

This section describes design and indicators layout of the device. Images of the front, back and side panels of the device are shown in the section, connectors, LED indicators and controls are described.

NTU-MD500P is enclosed in a metal case suitable for 19" rack, the height of the case is 1U.

#### 3.4.1 Front panel layout

The device front panel layout is shown in [Figure 2](#).




Figure 2 – NTU-MD500P front panel

Table 2 – Description of connectors and front panel controls

No	Front panel element	Description
1	Power	Device power indicator
	Status	Device operation indicator
	Alarm	Indicator of optical signal absence
	Link	Indicator of optical interface operation
	PoE 1-4	Status indicators of PoE ports
2	F	Functional button to restart the device and reset to factory settings: - pressing the button for less than 10 seconds restarts the device; - pressing the button for more than 10 seconds resets the device to the factory settings.
3	LAN 10/100/1000 1..4	4 RJ-45 ports for connecting network devices
4	PON	PON SC port (socket) of the GPON optical interface
5	110-250 V AC 50-60 Hz	Connector for AC power source

### 3.4.2 Side and back panels of the device




Figure 3 – NTU-MD500P back panel

№	Back panel element
1	Earth bonding point




Figure 4 – NTU-MD500P left-side panel

There are ventilation grilles on the side and back panels of the device, which serve to remove heat. Do not cover the ventilation grilles, it can lead to overheating of the device components and cause malfunctioning. See recommendations for device installation in the [Installing and connecting NTU-MD500P](#) section.

### 3.5 Light indication

System indicators (Power, Status, Alarm, Link) are used to determine the operation status of the device nodes.

Table 3 – Light indication of device status

Indicator name	Indicator status	Device status
<b>Power</b>	Solid green	The power is on, the device is operating normally
	Off	The power is off
<b>Status</b>	Solid red	The moment the drivers are launching
	Solid green	The device has a configuration which differs from the default one
	Green, flashing slowly	The default configuration is set on the device
<b>PoE 1-4</b>	Solid green	The PoE consumer is connected, the power supply is in on (the indicator corresponds to a port).
	Solid red	PoE error on port
	Off	PoE consumer is not connected
<b>Alarm</b>	Off	Normal operation of the device
	Solid red	There is no optical signal
<b>Link</b>	Off	The device is loading
	Green, flashing fast	Getting settings via OMCI
	Solid green	The device has been successfully configured via OMCI.
	Green, flashing slowly	Configuration is absent (authorization)
	Red, flashing slowly	No signal from OLT
<b>LAN P1..P4</b>	Green	10/100 Mbps connection has been established
	Orange	1000 Mbps connection has been established
	Flashing	The process of packet data transmission

### 3.6 Delivery package

The basic delivery package of NTU-MD500P device includes:

- Subscriber terminal NTU-MD500P;
- Power cord with euro plug C-13, 1.8 m;
- Mounting kit for installing into 19" rack;
- Technical passport.

## 4 Installing and connecting NTU-MD500P

### 4.1 Operating conditions and installation procedure

This chapter describes procedure of installation into 19" rack and connection to a power supply.

#### 4.1.1 Safety requirements

##### General requirements

When working with the device, it is necessary to comply with safety regulations for the operation with electrical installations.

❗ It is forbidden to work with the device to persons who are not allowed to operation in accordance with the safety requirements.

1. The operation of the device must be carried out by engineering and technical personnel who have received special training.
2. Connect only fault-free auxiliary equipment to the terminal.
3. The terminal is designed for twenty-four-hour operation under the following conditions:
  - ambient temperature from 0 to +40 °C;
  - relative humidity up to 80 % at 25 °C;
  - atmospheric pressure from  $6.0 \times 10^4$  Pa to  $10.7 \times 10^4$  Pa (from 450 to 800 mm Hg).
4. Do not expose the device to mechanical shocks and vibrations, as well as smoke, dust, water, chemicals.
5. In order to avoid overheating of the device components and disruption of its operation, it is forbidden to cover the ventilation grilles and place objects on the surface of the device.

#### Electrical safety requirements

1. Before connecting the terminal to a power source, it is necessary to ground the device case using the earth bonding point (Figure 3). A grounding wire must be securely fixed to the earth bonding point. The resistance value between the earth bonding point and ground bus must not exceed 0.1 Ohm. Before connecting measuring instruments and a PC to the device, they must be previously grounded. The potential difference between the device case and measuring instruments should not exceed 1 V.
2. Before turning on the device, make sure that the cables are intact and securely attached to the connectors.
3. When installing or removing the case, make sure that the power supply of the device is switched off.

#### 4.1.2 Installation procedure

Before installing and switching on, it is necessary to check the device for visible mechanical damage. In case of damage, stop installing the device, draw up an appropriate report and contact the supplier. If the device has been exposed to low temperature for a long period of time, it should be kept at room temperature for two hours before operation. After a long stay of the device in high humidity conditions, it is necessary to keep it under normal conditions for at least 12 hours before switching on.

##### Mounting

The terminal package includes brackets for installation in a rack and screws for fixing brackets to the device case. To install the brackets:

- **Step 1.** Align the four screw holes on the bracket with the same holes on the side panel of the device.
- **Step 2.** Using a screwdriver, attach the bracket with screws to the case.
- **Step 3.** Repeat steps 1 and 2 for the second bracket.




Figure 5 – Mounting brackets

### Installing into a rack

To install the device in a rack:

- **Step 1.** Attach the device to the vertical rails of the rack.
- **Step 2.** Align the holes of the brackets with the holes on the rack rails. Use the holes in the rails at the same level on both sides of the rack so that the device will be positioned strictly horizontally.
- **Step 3.** Use a screwdriver to attach the device to the rack with screws.




Figure 6 – Mounting brackets

The device has horizontal ventilation. Ventilation grilles are located on the side panels of the device. Do not cover the ventilation grilles to avoid overheating of the device components and malfunctioning.

**⚠** To avoid overheating and provide the necessary ventilation, the device must be placed so that there is at least 10 cm of free space above and below it.

## 4.2 Connecting the device

1. Connect LAN port of NTU-MD500P and Ethernet port of your PC using an Ethernet cable.




Figure 7 – Connecting the device to the computer

2. Connect the optical cable provided by the Internet service provider to the PON connector of the device.




Figure 8 – Connecting the device to an Internet service provider's network

3. Connect the terminal to 220 V power supply network using the power adapter included into the delivery package. Wait until the device is fully loaded.




Figure 9 – Connecting the device to the power supply

## 5 Device architecture




Figure 10 – Logical architecture of the device with the factory configuration

### The main elements of the device:

- **Optical transceiver (SFF module)** is designed to convert an optical signal into an electrical one;
- **Processor (PON chip)** – is a converter of Ethernet and GPON interfaces.

In the factory configuration, the following logic blocks are present (Figure 10):

- Br0;
- eth0...3;
- IPInterface1.

The **br0** block in this case is intended for combining LAN ports into one group.

The **eth0..3** blocks are physically Ethernet ports with an RJ-45 connector for connecting a PC, STB or other network devices. Logically included in the **br0** block.

The **Filter** and **Marking** blocks are designed to put local interfaces in one group (in the **br0** block). These blocks are responsible for the traffic transmission rules, the **Filter** blocks are responsible for incoming traffic on the interface, the **Marking** blocks are responsible for outgoing traffic.

The **ipinterface1** block is a logical object where IP address for access to the local network is stored, as well as a DHCP server that distributes addresses to clients.

## 6 Configuring the device via web interface. Admin access.

### Getting started

To configure the device, you need to connect the device via a web browser:

1. Open a web browser (web page viewer), for example, Firefox, Google Chrome.
2. Type the device IP address in the browser's address bar

✔ The default IP address: *192.168.0.1*, subnet mask: *255.255.255.0*

If the connection is successful, a page with the authorization request will be displayed in the browser window:

3. Enter username and password

✔ Default user name – *admin*, password – *password*.

4. Click the "Login" button. The starting page of the device's web interface will be displayed in the browser window.

### Changing the password

In order to avoid unauthorized access, it is recommended to change the password for further operation. To change the password in the menu *Admin*, section "*Password*", in the field "*Old Password*" enter the current password in the fields "*New Password*" and "*Confirm new password*" enter a new password. To save changes, click the **Apply Changes** button.

## Elements of the web interface

General view of the device configuration window is shown below.

The screenshot displays the web interface for the ELTEX NTU-MD500P device. The interface is divided into three main parts:

- 1. Navigation Tree:** A sidebar on the left containing menu items: Status, LAN, WAN, Services, Advance, Diagnostics, Admin, and Statistics.
- 2. Main Content Area:** The central part of the page showing the 'Device Status' section. It includes a 'System' table with various device details, 'LAN Configuration' table, 'WAN Configuration' table, and 'L2TP Configuration' table. A 'Refresh' button is located at the bottom of this section.
- 3. User Management:** A top right corner area showing the current user 'admin' and a 'Logout' button.

**System Configuration Table:**

Board Type	NTU-MD500P
Serial Number	GP51000024
PON Serial	454C545882000003
Base WAN MAC	E4:5A:D4:ED:E2:1F
Hardware Version	1v1
Uptime	1:29
Date/Time	Thu Jan 1 01:29:39 1970
Image 1 Firmware Version (Active)	2.4.1.323
Image 2 Firmware Version	
CPU Usage	1%
Memory Usage	11%
Name Servers	
IPv4 Default Gateway	
IPv6 Default Gateway	

**LAN Configuration Table:**

IP Address	192.168.0.1
Subnet Mask	255.255.255.0
DHCP Server	Enabled
MAC Address	e4:5a:d4:ed:e2:1f

**WAN Configuration Table:**

Interface	VLAN ID	MAC	Connection Type	Protocol	IP Address	Subnet Mask	Gateway	NAPT	Firewall	IGMP Proxy	802.1p	Status

**L2TP Configuration Table:**

Interface	Protocol	Local IP Address	Remote IP Address	Status

The user interface can be divided into 3 parts :

1. The navigation tree of the device settings menu.
2. The main window of selected section settings.
3. Change user button.

## 6.1 Status menu. Device information

### 6.1.1 Device submenu. General information on the device

The section displays general information on the device, the main parameters of LAN and WAN interfaces.

*Status → Device*

**Device Status**

This page shows the current status and some basic settings of the device.

**System**

Board Type	NTU-MD500P:rev.B
Serial Number	GP5F000024
PON Serial	454C54588F000003
Base WAN MAC	CC:9D:A2:DC:DC:0C
Hardware Version	2v0
Uptime	6 days, 8 min
Date/Time	Wed Jan 7 00:08:32 1970
Image 1 Firmware Version (Active)	2.4.7.52
Image 2 Firmware Version	2.4.7.52
CPU Usage	1%
Memory Usage	11%
Name Servers	
IPv4 Default Gateway	
IPv6 Default Gateway	

**LAN Configuration**

IP Address	192.168.0.1
Subnet Mask	255.255.255.0
DHCP Server	Enabled
MAC Address	cc:9d:a2:dc:dc:0c

**WAN Configuration**

Interface	VLAN ID	MAC	Connection Type	Protocol	IP Address	Subnet Mask	Gateway	NAPT	Firewall	IGMP Proxy	802.1p	Status

**L2TP Configuration**

Interface	Protocol	Local IP Address	Remote IP Address	Status

Refresh

### System

- *Board Type* – hardware model;
- *Serial Number* – serial number of the device;
- *PON Serial* – serial number of the device in PON network;
- *Base WAN MAC* – WAN MAC address of the device;
- *Hardware Version* – hardware version of the device;
- *Uptime* – device operation time;
- *Date/Time* – the current time on the device;
- *Image 1 Firmware Version (Active)* – current firmware version;
- *Image 2 Firmware Version* – backup software version;
- *CPU Usage* – percentage of CPU usage;
- *Memory Usage* – percentage of memory usage;
- *Name Servers* – name of DNS server;
- *IPv4 Default Gateway*;
- *IPv6 Default Gateway*.

### LAN Configuration

- *IP Address* – IP address of the device;
- *Subnet Mask* – network mask of the device;
- *DHCP Server* – status of DHCP server;
- *MAC Address* – MAC address of the device.

### WAN Configuration

- *Interface* – interface name;
- *VLAN ID* – VLAN ID of the interface;
- *MAC* – MAC address of the interface;
- *Connection Type*;
- *Protocol* – the protocol used;
- *IP Address* – IP address of the interface;
- *Subnet Mask*;
- *Gateway*;
- *NAPT* – NAPT state;
- *Firewall* – firewall status;
- *IGMP Proxy* – IGMP Proxy status;
- *802.1p* – 802.1p mark;
- *Status* – interface status.

### L2TP Configuration


- *Interface* – interface name;
- *Protocol* – the protocol used;
- *Local IP Address* – the IP address of the L2TP interface;
- *Remote IP Address* – server IP address;
- *Status* – interface status.

To update the data on the page, click **Refresh**.

### 6.1.2 IPv6 Status submenu. IPv6 System Information

The section displays the current status of the IPv6 system.

*Status* → *IPv6*



### LAN Configuration

- *IPv6 Address*;
- *IPv6 Link-Local Address* – local IPv6 address.

### Prefix Delegation

- *Prefix* – prefix of IPv6 address.

### WAN Configuration

- *Interface* – interface name;
- *VLAN ID* – VLAN ID of the interface;
- *Connection Type*;

- *Protocol* – the protocol used;
- *IP Address* – IP address of the interface;
- *Status* – interface status.

To update the data on the page, click **Refresh**.

### 6.1.3 PON submenu. Optical module status

The section shows the current state of the PON interface.

*Status* → *PON*

**PON Status**

This page shows the current system status of PON.

PON Status	
Vendor Name	
Part Number	
Temperature	45.148438 C
Voltage	3.352300 V
Tx Power	4.185333 dBm
Rx Power	-inf dBm
Bias Current	6.250000 mA

GPON Status	
ONU State	01
ONU ID	255
LOID Status	Initial Status

#### **PON Status**

- *Vendor Name* – PON chipset vendor's name;
- *Part Number* – part number of PON chipset;
- *Temperature* – current temperature;
- *Voltage*;
- *Tx Power* – transmission power;
- *Rx Power* – signal power at reception;
- *Bias Current*.

#### **GPON Status**

- *ONU State* – a status of authorization on OLT (01 -> 02 -> 03 -> 04 -> 05);
- *ONU ID* – device ID on OLT;
- *LOID Status* – authorization status on OLT (Initial -> Standby -> Serial Number -> Ranging - Operation).

To update the data on the page, click **Refresh**.

### 6.1.4 LAN submenu. Information on the status of LAN interface

In this section, you can view the main parameters of LAN interfaces.

#### Status → LAN

LAN Port	Status
LAN1	Up; 1000M, Full Mode
LAN2	Down
LAN3	Down
LAN4	Down

To update information in the table, click **Refresh**.

## 6.2 LAN menu. Configuring LAN interface

In this section, you can configure the main characteristics of wired and wireless LAN interfaces.

### LAN

InterfaceName:	LANIPInterface
IP Address:	192.168.0.1
Subnet Mask:	255.255.255.0
IPv6 Address:	fe80::1
IPv6 DNS Mode:	HGWProxy
Prefix Mode:	WANDelegated
WAN Interface:	
Firewall:	<input checked="" type="radio"/> Disabled <input type="radio"/> Enabled
IGMP Snooping:	<input type="radio"/> Disabled <input checked="" type="radio"/> Enabled

- *InterfaceName* – interface name;
- *IP Address* – IP address of the interface;
- *Subnet Mask* – interface subnet mask;
- *IPv6 Address*;
- *IPv6 DNS Mode* – configure the mode of domain names usage:
  - *HGWProxy* – configure DNS mode for IPv6;
  - *WANConnection* – use the WAN interface to get the DNS server address;
  - *Static* – specify a static DNS server address (IPv6 DNS1, IPv6 DNS2).
- *Prefix Mode* – configure prefix reception mode (from WAN interface or statically):
  - *WANDelegated* – the option of delegating prefixes received from the provider;
  - *Static* – specify prefix statically.
- *WAN Interface* – select WAN interface to be used when WANDelegated.
- *Firewall (Enabled/Disabled)* – enable/disable firewall for LAN interface;
- *IGMP Snooping (Enabled/Disabled)* – enable/disable IGMP Snooping.

To save changes, click **Apply Changes**.

## 6.3 WAN menu. Configuring WAN interface

### 6.3.1 PON WAN submenu

In this section, you can configure the PON WAN parameters.

WAN → PON WAN

- *Enable VLAN*;
- *VLAN ID* – VLAN identification number;
- *802.1p\_Mark* – 802.1p priority;
- *Channel Mode* – VLAN interface operation mode;
  - *Bridged*;
  - *IPoE* – getting an address via the DHCP protocol;
  - *PPPoE* – installing a point-to-point tunnel over Ethernet.
- *Interface Grouping* – select a group of interfaces;
- *Group name* – name of the interface group;
- *Enable NAPT* – enable NAPT (Network address port translation) function;
- *Admin Status (Enable/Disable)* – enable/disable administrative status;
- *Enable Firewall*;
- *Connection Type* – type of service provided on the WAN;
- *Default Route (Enable/Disable)* – enable/disable the use of the selected interface as a default gateway;
- *Enable IGMP-Proxy* – enable interception and forwarding of IGMP messages.

To save changes, click **Apply Changes**, to delete – **Delete**.

## 6.3.2 VPN submenu

### 6.3.2.1 L2TP submenu. Setting up an L2TP VPN

In this section, you can configure the virtual connection parameters L2TP VPN. The L2TP protocol is used to create a secure connection channel over the Internet between a remote user's computer and a local computer.

WAN → VPN → L2TP

**L2TP VPN Configuration**

This page is used to configure the parameters for L2TP mode VPN.

**L2TP VPN:**  Disable  Enable

**Server:**

**Tunnel Authentication:**

**Tunnel Authentication Secret:**

**PPP Authentication:** Auto

**PPP Encryption:** NONE

**UserName:**

**Password:**

**PPP Connection Type:** Persistent

**Idle Time (min):**

**MTU:** 1458

**Default Gateway:**

**L2TP Table:**

Select	Interface	Server	Tunnel Authentication	PPP Authentication	MTU	Default Gateway	Action
<input type="button" value="Delete Selected"/>							

L2TP VPN is a mode in which access to the Internet is carried out through a tunnel using the L2TP protocol. When **Enable** is selected, the following parameters will be available for editing:

- *Server* – L2TP server address (domain name or IP address in IPv4 format);
- *Tunnel Authentication* – enable authentication;
- *Tunnel Authentication Secret* – authentication key;
- *PPP Authentication* – select authentication protocol used on L2TP server to validate connections;
- *PPP Encryption* – select data encryption protocol to be used (only for the CHAPMSv2 authentication method);
- *UserName* – the username for authorization on L2TP server;
- *Password* – password for authorization on L2TP server;
- *PPP Connection Type*;
- *Idle Time (min)* – idle time in seconds, breaks an inactive connection after a specified time (only for establishing a connection on demand (dial-on-demand));
- *MTU* – the maximum size of the data block transmitted over the network (the recommended value is 1462);
- *Default Gateway* – select whether the created tunnel will be a default L2TP gateway.

To save changes, click **Apply Changes**.

In the **L2TP Table**, you may view the status of a virtual L2TP VPN connection. To delete a certain entry, select the position and click **Delete Selected**.

### 6.3.2.2 IPsec submenu. Configuring IP Security

This page is used to configure settings for VPN in IPsec mode.

WAN → VPN → IPsec

- **Negotiation Type** – select the type of negotiation: automatic or manual one;
  - **Negotiation Type – Automatic:**
    - **Mode** – IPsec operation mode (only transport mode is supported);
    - **Remote Tunnel Addr.** – server IP address;
    - **Local Tunnel Addr.** – local IP address;
    - **Security Option:**
      - **Encapsulation Type;**
      - **IKE Auth Method** – IKE authentication method (Pre-shared key or Certificate);
      - **Pre shared key** – set shared key (if using Pre-shared key method);
      - **Advanced Option** – set up advanced security options:
        - **Filter Option:**
          - **Protocol;**
          - **Port.**
        - **IKE Phase 1** – setting up the first phase:
          - **Negotiation Mode** – negotiation mode: main or aggressive;
          - **Keepalive Time** – session uptime in seconds;
          - **IKE Algorithm 1-4** – select key exchange algorithms.
        - **IKE Phase 2** – setting up the second phase:
          - **pfs\_group mode** – select PFS(DH) group;
          - **Encrypt Algorithm** – encryption algorithm;
          - **Auth Algorithm** – authentication algorithm;
          - **Keepalive Time** – session uptime in seconds;
          - **Keepalive Byte** – bytes to keep session active, KB.

- *Negotiation Type* – Manual:
  - *Mode* – IPsec operation mode (only transport mode is supported);
  - *Remote Tunnel Addr.* – server IP address;
  - *Local Tunnel Addr.* – local IP address;
  - *Security Option*:
    - *Encapsulation Type*;
      - *Encapsulation Type* – ESP:
        - *ESP Encrypt Algorithm* – ESP encryption algorithm;
        - *ESP Encrypt Key* – ESP encryption key;
        - *ESP Auth Algorithm* – ESP authentication algorithm;
        - *ESP Auth Key* – ESP authentication key.
      - *Encapsulation Type* – AH:
        - *AH Auth Algorithm* – AH authentication algorithm (md5 or sha1);
        - *AH Auth* – AH authentication key.
      - *Encapsulation Type* – ESP+AH:
        - *ESP Encrypt Algorithm* – ESP encryption algorithm;
        - *ESP Encrypt Key* – ESP encryption key;
        - *ESP Auth Algorithm* – ESP authentication algorithm;
        - *ESP Auth Key* – ESP authentication key;
        - *AH Auth Algorithm* – AH authentication algorithm;
        - *AH Auth* – AH authentication key.
    - *Advanced Option* – set up advanced security options;
    - *Filter Option*:
      - *Protocol*;
      - *Port*.
- *Certificate Management* – select and download a management certificate. Click **Select File** to select the certificate then click **Upload**.

To save changes, click **Add/Save**.

In the table **IPsec Information List**, you can view, enable, disable and delete (**Delete Selected**) the created rules.

## 6.4 Services menu. Configuring services

### 6.4.1 DHCP Settings submenu. Configuring DHCP

In this section, a DHCP server or a DHCP repeater is configured.

- *DHCP Mode* – select operation mode:
  - *NONE* – DHCP is disabled;
  - *DHCP Server* – operation in the DHCP server mode;
  - *DHCP Relay* – operation in the DHCP relay mode.

*Services* → *DHCP (DHCP Server is selected)*

**DHCP Settings**

This page is used to configure DHCP Server and DHCP Relay.

**DHCP Mode:**  NONE  DHCP Relay  DHCP Server

Enable the DHCP Server if you are using this device as a DHCP server. This page lists the IP address pools available to hosts on your LAN. The device distributes numbers in the pool to hosts on your network as they request Internet access.

**LAN IP Address:** 192.168.0.1 **LAN Subnet Mask:** 255.255.255.0

**IP Pool Range:**  -

**Subnet Mask:**

**Max Lease Time:**  seconds (-1 indicates an infinite lease)

**DomainName:**

**Gateway Address:**

**DNS option:**  Use DNS Proxy  Set Manually

- *IP Pool Range* – the range of addresses issued to clients;
- *Show Client* – a button for viewing clients who have leased addresses. When enabled, a table with information about the DHCP clients leased addresses is displayed;
- *Subnet Mask* – subnet mask;
- *Max Lease Time* – maximum lease time, -1 for timeless lease;
- *DomainName* – domain name;
- *Gateway Address* – gateway address;
- *DNS option* – defines DNS operation:
  - *Use DNS relay* – the ONT address will be issued as DNS and all requests will be relayed via ONT;
  - *Set manually* – set DNS manually.

To save changes, click **Apply Changes**.

**Port-Based Filter** configures filtering according to ports, **MAC-Based Assignment** – according to MAC addresses.

Services → DHCP (DHCP Relay is selected)

- *DHCP Server IP Address* – IP address of remote DHCP server, which will be used for DHCP Relay.

To save changes, click **Apply Changes**.

## 6.4.2 DNS submenu

### 6.4.2.1 Dynamic DNS submenu. Dynamic Domain Name System Settings

Dynamic DNS (dynamic domain name system) allows updating information on DNS server in real time and (optionally) in automatic mode. It is used to assign a permanent domain name to a device (computer, router, for example NTU-RG) having dynamic IP address. IP address might be obtained via IPCP in PPP connections or via DHCP.

Dynamic DNS is often used in local networks, where clients receive an IP address via DHCP, and then register their names in the local DNS server.

Services → DNS → Dynamic DNS

- *Enable* – when selected, DHCP server is used (network devices will receive IP addresses dynamically, from the range below);
- *D-DNS Provider* – select the type of D-DNS service (provider): DynDNS.org, No-IP.com;

- *Hostname/Interface* – if you use another provider, you should specify the name (*Hostname*) and address (*Interface*) of the provider manually.

#### *DynDns/No-IP Settings:*

- *UserName* – user name;
- *Password* – password for authorization on the service selected for D-DNS operation.


The section displays **Dynamic DNS Table** with a list of available DNS and its parameters. To add an entry, click **Add**. To change/delete a position, select it and click **Modify** or **Remove**.

### 6.4.3 Firewall submenu. Configuring the firewall

#### 6.4.3.1 ALG On-Off Configuration submenu. Enabling disabling ALG services.

In this section, you can enable or disable ALG and Pass Through services.

*Services* → *Firewall* → *ALG*



Please, do not forget to click **Apply changes**, to save changes made.

### 6.4.3.2 IP/Port Filtering submenu. Configuring address filtering

Address filtering settings are available in this menu. The IP filtering function allows you to filter traffic passing through the router according to IP addresses and ports. The use of such filters can be useful to protect or put restrictions on the local network.

Services → Firewall → IP/Port Filtering

The screenshot shows the 'IP/Port Filtering' configuration page. On the left is a navigation tree with 'Services' expanded to 'Firewall' and 'IP/Port Filtering' selected. The main content area has the following sections:

- IP/Port Filtering**: A heading with a sub-note: "Entries in this table are used to restrict certain types of data packets through the Gateway. Use of such filters can be helpful in securing or restricting your local network."
- Outgoing Default Action**: Radio buttons for Deny and Allow, with 'Allow' selected.
- Incoming Default Action**: Radio buttons for Deny and Allow, with 'Deny' selected.
- Apply Changes**: A button.
- Filter Rule Form**: Fields for Direction (Outgoing), Protocol (TCP), Rule Action (Deny), Source IP Address, Subnet Mask, Port, Destination IP Address, Subnet Mask, Port, and WAN Interface (Any). An 'Add' button is below.
- Current Filter Table**: A table with columns: Select, Direction, Protocol, Source IP Address, Source Port, Destination IP Address, Destination Port, WAN Interface, Rule Action. Below the table are 'Delete Selected' and 'Delete All' buttons.

#### Default settings

- *Outgoing Default Action Deny/Allow* – filtering of outgoing packets;
- *Incoming Default Action Deny/Allow* – filtering of incoming packets.

To save changes made, click **Apply Changes**.

To add a filter, complete the appropriate fields and click **Add**:

- *Direction* – direction of packet transmission (outgoing/incoming);
- *Protocol* – filtering protocol;
- *Rule Action* – packet processing policy (Deny/Allow);
- *Source IP Address*;
  - *Subnet mask*;
  - *Port*.
- *Destination IP Address*;
  - *Subnet mask*;
  - *Port*.
- *WAN Interface* – incoming interface.

The added filters are displayed in **Current Filter Table**. The entries in this table are used to restrict certain types of data packets through the gateway. To delete a certain filter, select an entry and click the **Delete selected** button, to delete all filters – **Delete All**.

### 6.4.3.3 MAC Filtering submenu. MAC address filtering settings

The section helps to configure filtration based on MAC addresses, which allows you to forward or block traffic according to MAC address of the source and recipient.

Services → Firewall → MAC Filtering

MAC Filtering for bridge mode

Entries in this table are used to restrict certain types of data packets from your local network to Internet through the Gateway. Use of such filters can be helpful in securing or restricting your local network.

Outgoing Default Action  Deny  Allow

Incoming Default Action  Deny  Allow

Direction:

Source MAC Address:

Destination MAC Address:

Rule Action  Deny  Allow

Current Filter Table:

Select	Direction	Source MAC Address	Destination MAC Address	Interface	Rule Action
<input type="button" value="Delete Selected"/> <input type="button" value="Delete All"/>					

- *Outgoing Default Action* – default packet processing policy for outgoing traffic (Deny (drop out) / Allow (transmit));
- *Incoming Default Action* – default packet processing policy for incoming traffic (Deny (drop out) / Allow (transmit)).

To save changes, click **Apply Changes**.

To add a filter, complete the appropriate fields and click **Add** button:

- *Direction* – direction of packet transmission (outgoing/incoming);
- *Source MAC Address* – add source MAC address for which you want to set restriction/access.
- *Destination MAC Address* – add destination MAC address for which you want to set restriction/access.
- *Rule Action* – packet processing policy (Deny (drop out) / Allow (transmit));
- *WAN Interface* – incoming interface.

The added filters are displayed in the filter table below – **Current Filter Table**. The *Rule action* field displays the type of rule created (**Allow** or **Deny** traffic transmission). To delete a certain rule in the list, select it and click **Delete Selected**, to delete the entire list, click **Delete All**.



### 6.4.3.5 URL Blocking submenu. Configuring the Internet access restriction

The URL filter performs full analysis and control for access to certain Internet resources. In this section you may set and view a list of prohibited/allowed URLs to visit. Here you can add a prohibited/permitted FQDN (Fully Qualified Domain Name) with the **Add** button, keyword filtering is also possible. The added restrictions are displayed in **URL Blocking Table** and **Keyword Filtering Table**, to delete a specific URL or keyword from the table, click on it, and then on the **Delete Selected** button. To remove all restrictions, click **Delete All**.

Services → Firewall → URL Blocking

The screenshot shows the 'URL Blocking' configuration page. On the left is a navigation tree with 'URL Blocking' selected under 'Firewall'. The main content area has the following elements:

- URL Blocking:** Radio buttons for 'Disable' (selected) and 'Enable', followed by an 'Apply Changes' button.
- FQDN:** A text input field and an 'Add' button.
- URL Blocking Table:** A table with a header row containing 'Select' and 'FQDN'. Below the table are 'Delete Selected' and 'Delete All' buttons.
- Keyword:** A text input field and an 'Add' button.
- Keyword Filtering Table:** A table with a header row containing 'Select' and 'Filtered Keyword'. Below the table are 'Delete Selected' and 'Delete All' buttons.

- *URL Blocking (Enable/Disable)* – enabling/disabling URL-Blocking;
- *FQDN (Fully Qualified Domain Name)* – full domain name;
- *Keyword* – keyword.

To save changes, click **Apply Changes**.

### 6.4.3.6 Domain Blocking submenu. Setting up Domain Blocking

This section is used to specify domain blocking.

Services → Firewall → Domain blocking

The screenshot shows the 'Domain Blocking Configuration' page. On the left is a navigation tree with 'Domain Blocking' selected under 'Firewall'. The main content area has the following elements:

- Domain Blocking:** Radio buttons for 'Disable' (selected) and 'Enable', followed by an 'Apply Changes' button.
- Domain:** A text input field and an 'Add' button.
- Domain Blocking Configuration:** A table with a header row containing 'Select' and 'Domain'. Below the table are 'Delete Selected' and 'Delete All' buttons.

To block a domain, select **Enable**, complete the **Domain** field and click the **Add** button.

- *Domain Blocking (Enable/Disable)* – enable/disable blocking;
- *Domain* – domain name.

To save changes, use the **Apply Changes** button. All blocked domains are listed in the **Domain Blocking Configuration** table, to remove the block for a certain domain, select it and click **Delete Selected**, to remove all restrictions, click **Delete All**.

#### 6.4.3.7 DMZ submenu. Configuring demilitarized zone

When setting IP address in the *DMZ Host IP Address* field, all requests from the external network that do not meet the *Port Forwarding* rules will be sent to the DMZ host (a trusted host with the specified address located in the local network).

Services → Firewall → DMZ

- *DMZ Host (Enable/Disable)* – enabling/disabling the host;
- *DMZ Host IP Address* – IP address.

To save changes, click the **Apply Changes** button.

#### 6.4.4 UPnP submenu. Automatic configuration of network devices

In this section, you may configure the Universal Plug and Play (UPnP) function. UPnP provides compatibility with network equipment, software, and peripherals.

Services → UPnP

✔ To use UPnP, you need to configure NAT on the active WAN interface.

- *UPnP (Enable/Disable)* – enable/disable UPnP function;
- *WAN Interface* – WAN interface on which the UPnP function will be enabled.

To save settings, click **Apply Changes**.

#### 6.4.5 RIP submenu. Configuring dynamic routing

In this section you may select interfaces on devices that will use RIP and its version. Enable RIP if you are using this device as a RIP-enabled device to communicate with other users using the RIP Dynamic Routing protocol.

Services → RIP

**RIP Configuration**

Enable the RIP if you are using this device as a RIP-enabled Device to communicate with others using the Routing Information Protocol. This page is used to select the interfaces on your device is that use RIP, and the version of the protocol used.

RIP:  Disable  Enable

Interface:

Receive Mode:

Send Mode:

**RIP Config Table:**

Select	Interface	Receive Mode	Send Mode
<input type="checkbox"/>			

- *RIP (Enable/Disable)* – enabling/disabling the use of the RIP dynamic routing protocol;

To accept and save settings, click **Apply Changes**.

- *Interface* – the interface on which RIP will be launched;
- *Receive Mode* – incoming packet processing mode (NONE, RIP1, RIP2, both);
- *Send Mode* – transmission mode (NONE, RIP1, RIP2, RIP1 COMPAT).

RIP-enabled interfaces are displayed in **RIP Config Table**. To delete all entries in the table, click **Delete All**, to delete a certain entry from the list, select it and click **Delete Selected**.

## 6.5 Advance menu. Advanced settings

### 6.5.1 ARP Table submenu. Viewing the ARP protocol cache

The section displays a table of learned MAC addresses. The efficiency of ARP operation largely depends on the ARP cache, which is present on each host. The cache contains Internet addresses and their corresponding hardware addresses. The lifetime of each entry in the cache is 5 minutes from the moment the entry was created.

*Advance → ARP table*

**User List**

This table shows a list of learned MAC addresses.

IP Address	MAC Address
192.168.0.10	a0:a3:f0:d0:f5:0f

Refresh

- *IP Address* – the client's IP address;
- *MAC Address* – the MAC address of the client.

To update information in the table, click **Refresh**.

### 6.5.2 Bridging submenu. Configuring Bridging parameters

In this section, you may configure bridge parameters. Here you can configure the lifetime of addresses in the MAC table, as well as enable/disable the 802.1d Spanning Tree protocol.

*Advance → Bridging*

**BridgingConfiguration**

This page is used to configure the bridge parameters. Here you can change the settings or view some information on the bridge and its attached ports.

**Ageing Time:**  (seconds)

**802.1d Spanning Tree:**  Disabled  Enabled

Apply Changes Show MACs

- *Aging Time* – lifetime of addresses (sec);
- *802.1d Spanning Tree (Enable/Disable)* – enabling/disabling 802.1d Spanning Tree protocol.

To save changes, click **Apply Changes**.

To view information on the bridge and its connected ports, click **Show MACs**.

*Advance → Bridging → Show MACs*

**Bridge Forwarding Database**

This table shows a list of learned MAC addresses.

Port	MAC Address	Is Local?	Ageing Timer
1	a0:a3:f0:d0:f5:0f	no	0.01

- *Port* – port number;
- *MAC Address* – MAC address;
- *Is Local* – local address;
- *Aging Timer* – address lifetime.

To update information in the table, click **Refresh**, to close – **Close**.

### 6.5.3 Routing submenu. Configuring routing

The section is used to configure static routing.

*Advance → Routing*

- Status
- LAN
- WAN
- Services
- Advance
  - ARP Table
  - Bridging
  - Routing
  - Interface Grouping
  - IP QoS
  - PoE Settings
  - Link Mode
  - Others
  - IPv6
- Diagnostics
- Admin
- Statistics

**RoutingConfiguration**

This page is used to configure the routing information. Here you can add/delete IP routes.

---

**Enable:**

**Destination:**

**Subnet Mask:**

**Next Hop:**

**Metric:**

**Interface:** Any ▼

---

**Static Route Table:**

Select	State	Destination	Subnet Mask	Next Hop	Metric	Interface
--------	-------	-------------	-------------	----------	--------	-----------

To add a static route, select **Enable**, complete the appropriate fields and click **Add Route**.

- *Enable* – add a route;
- *Destination* – destination address;
- *Subnet Mask* – subnet mask;
- *Next Hop* – next node;
- *Metric* – metric;
- *Interface* – interface.

Added static routes are displayed in **Static Route Table**. To update the information in the table, click **Update**, to delete an entry from the table, select it and click **Delete Selected**.

To view the routes that the device frequently accesses, click **Show Routes**, then *IP Route Table* will be displayed.

Advance → Routing → Show Routes

**IP Route Table**

This table shows a list of destination routes commonly accessed by your network.

Destination	Subnet Mask	Next Hop	Metric	Interface
127.0.0.0	255.255.255.0	*	0	lo
192.168.0.0	255.255.255.0	*	0	br0

Refresh Close

To update information in the table, click **Refresh**, to close it, click **Close**.

**6.5.4 Interface grouping submenu. Combining interfaces into groups**

In this section, you can combine interfaces into different groups. By default, all interfaces are in the same group. To transfer the interface to a new group, you should:

1. Select a new group from the list below;
2. Select interfaces from the list of Available interfaces;
3. Press the arrow ← to move the interfaces to the group;
4. Apply actions by clicking **Apply Changes**.

Advance → Interface grouping

Interface Grouping Configuration

Select: New Group v  
 Enable:   
 Name:

Grouped Interfaces	Available Interfaces
	LAN1 LAN2 LAN3 LAN4 LANIPInterface

Apply Changes


Name	Status	Interfaces	Action
default	Enable	LAN1,LAN2,LAN3,LAN4,LANIPInterface	

**6.5.5 IP QoS submenu. Configuring the quality of services provided (QoS)**

**6.5.5.1 QoS Policy submenu. Setting up QoS Queues**

In this section, you can configure QoS queue policies for traffic processing.

Advance → IP QoS → QoS Policy



- *IP QoS (Enable/Disable)* – enable/disable configuration of QoS queues;
- *Policy* – select policy:
  - *PRIO* – strict queue processing is used when selecting the PRIO policy. The smaller queue corresponds to the highest priority;
  - *WRR* – weighted queue processing will be used when selecting the WRR policy. By default, weight for queues is distributed as 40:30:20:10.

**QoS Bandwidth Config**

Is used to configure the bandwidth of individual services.


- *User defined Bandwidth (Enable/Disable)* – enable restriction;
- *Total Bandwidth Limit, (kb)* – bandwidth limit, kbit.

To save changes, click **Apply Changes**.

**6.5.5.2 QoS Classification submenu. Configuring traffic classification rules**

On this page, you can specify according to which fields and their values the packet will be classified, as well as which hardware queue it will eventually belong to.

Advance → IP QoS → QoS Classification



To add a rule, click **Add** and complete the appropriate fields.

## Advance → IP QoS → QoS Classification → Add

- *RuleName* – rule name;
- *RuleOrder* – sequence number.

**Assing IP Precedence/DSCP/802.1p** – setting up the assignment of IP fields.

- *Precedence* – queue selection;
- *DSCP* – priority in the IP packet header;
- *802.1p* – priority label in 802.1Q .

**Specify Traffic Classification Rules** – select traffic classification rule.


- *IP QoS Rule by type* – select classification rule according to the type:
  - *Port* – according to port;
    - *Physiact Port* – select physical port.
  - *Ethery Type* – according to Ethertype;
  - *IP/Protocol* – via IP protocol;
    - *IPv4*:
      - *Protocol* – select protocol;
      - *Source IP* – source IP address;
      - *Source Mask* – source mask;
      - *Destination IP* – Destination IP address;
      - *Destination Mask* – destination mask;
      - *Source Port* – source port;
      - *Destination Port* – destination port.
    - *IPv6*:
      - *Protocol* – select protocol;
      - *Source IP* – source IP address;
      - *Source Prefix Length* – the length of the source prefix;
      - *Destination IP* – Destination IP address;
      - *Destination Prefix Length* – the length of the destination prefix;
      - *Source Port* – source port;
      - *Destination Port* – destination port.
  - *MAC Address* – according to MAC address.
    - *Source MAC* – Source MAC address;
    - *Destination MAC* – destination MAC address.

To save changes, click **Apply Changes**.

### 6.5.5.3 Traffic Shaping submenu. Configuring traffic

In this section, you can specify traffic restrictions according to certain rules.


Advance → IP QoS → Traffic Shaping



- *Total Bandwidth Limit (kb)* – total bandwidth limit, kbit.

To add, click **Add** and complete the appropriate fields.

Advance → IP QoS → Traffic Shaping → Add




- *IP Version* – select the IP version;
- *Direction* – selection of the flow type, descending or ascending;
- *Protocol* – protocol;
- *Source IP* – source IP address;
- *Source Mask/Prefix Length* – mask/prefix length of the source subnet;
- *Destination IP* – destination IP address;
- *Destination Mask/Prefix Length* – mask/prefix length of the destination subnet;
- *Source Port* – source port;
- *Destination Port* – destination port;
- *Rate Limit (kb/s)* – speed limit, kbps.

To save the changes, click **Apply Changes**, to cancel, click **Close**.

### 6.5.6 PoE Settings submenu. Configuring PoE ports

This page is used to configure PoE settings. Here, you can enable/disable PoE on LAN ports; to do this, you need to select **Enable** or **Disable**.

Advance → PoE Settings




- *Port* – LAN port number (1-4);
- *PsE enabled*:
  - *Enabled* – PoE is enabled;
  - *Disabled* – PoE is disabled.
- *Power* – power consumption, W;
- *Voltage* – voltage, V;
- *Temperature* – temperature, °C;
- *Detection Status* – PoE port status;
- *Power Classification* – the power class of the connected PoE device;
- *Error Type* – type of error.

To save changes, click **Apply Changes**.

### 6.5.7 Link mode submenu. Configuring LAN ports

In this section, you can set the mode of LAN ports operation. **LAN1/2/3/4** fields are used to set up the operation mode. Available modes are *10M Half Mode*, *10M Full Mode*, *100M Half Mode*, *100M Full Mode* and *Auto Mode* (auto detection mode).

*Advance* → *Link mode*




To save changes, click **Apply Changes**.

### 6.5.8 Others submenu. Additional settings

In this section, you can configure end-to-end IP transmission for WAN interfaces, as well as enable/disable JumboFrame transmission.

*Advance* → *Others*



To save changes, click **Apply Changes**.

### 6.5.9 IPv6 submenu. Configuring IPv6 protocol

In this section, you can enable/disable IPv6; to do this, select **Enable** or **Disable**.

*Advance* → *IPv6*



To save changes, click **Apply Changes**.

### 6.5.9.1 RADVD submenu. Configuring RADVD

The section is used to configure RADVD (Router Advertisement Daemon).

Advance → IPv6 → RADVD

**RADVD Configuration**

This page is used to setup the RADVD's configuration of your Device.

<b>MaxRtrAdvInterval:</b>	<input type="text" value="600"/>
<b>MinRtrAdvInterval:</b>	<input type="text" value="198"/>
<b>AdvManagedFlag:</b>	<input checked="" type="radio"/> off <input type="radio"/> on
<b>AdvOtherConfigFlag:</b>	<input type="radio"/> off <input checked="" type="radio"/> on


- *MaxRtrAdvInterval* – maximum interval for sending RA (Router Advertisement);
- *MinRtrAdvInterval* – minimum interval for sending RA;
- *AdvManagedFlag* – enable/disable sending Managed flag to RA;
- *AdvOtherFlag* – enable/disable sending Other RA flag.

To save changes, click **Apply Changes**.

### 6.5.9.2 DHCPv6 submenu. Configuring DHCPv6 Server

The section is used to configure DHCPv6 server. By default, it works in auto-configuration mode (DHCPv6Server(Auto)) via prefix delegation.

Advance → IPv6 → DHCPv6



- *DHCPv6 Mode* – enable/disable the operation of DHCPv6 server;
- *NTP Server IP* – specify the IP address of NTP server for time synchronization;
- *Hostname* – specify the hostname;
- *MAC Address* – specify client's MAC address to bind the IP address;
- *IP Address* – specify client's IP address to bind to the MAC address.

To save changes, click **Apply Changes**. **Show Client** button is used to view a table of active IP addresses of DHCPv6 server.

Advance → IPv6 → DHCPv6 → Show Client



### 6.5.9.3 MLD proxy submenu. Configuring MLD proxy function

In this section, you can enable/disable the operation of the MLD-proxy; to do this, you need to select **Enable** or **Disable**.

*Advance → IPv6 → MLD proxy*


The screenshot shows the configuration page for MLD Proxy. On the left is a navigation tree with the following items: Status, LAN, WAN, Services, Advance, ARP Table, Bridging, Routing, Interface Grouping, IP QoS, PoE Settings, Link Mode, Others, IPv6, Diagnostics, Admin, and Statistics. The IPv6 submenu is expanded, showing: IPv6, RADVD, DHCPv6, MLD Proxy, MLD Snooping, IPv6 Routing, and IP/Port Filtering. The main content area is titled "MLD Proxy Configuration" and contains the text "This page be used to configure MLD Proxy." Below this, there are two configuration fields: "MLD Proxy:" with radio buttons for "Disable" (selected) and "Enable", and "WAN Interface:" with a dropdown menu. At the bottom of the configuration area is an "Apply Changes" button.

To save changes, click **Apply Changes**.

#### 6.5.9.4 MLD snooping submenu. Setting up the MLD snooping function

In this section, you can enable/disable MLD-snooping; to do this, you need to select **Enable** or **Disable**.

*Advance* → *IPv6* → *MLD snooping*



To save changes, click **Apply Changes**.

### 6.5.9.5 IPv6 routing submenu. Configuring IPv6 routes

Static IPv6 routes are configured in this section.

Advance → IPv6 → IPv6 routing

- *Enable* – add a route;
- *Destination* – destination address;
- *Next Hop* – next node;
- *Metric* – metric;
- *Interface* – interface.

To add IPv6 routing, complete the appropriate fields and click **Add Route**. The added routes are displayed in **Static IPv6 Route Table**, to update the information, click **Update**. To delete the entire table, click **Delete All**, to delete one route, select it and click **Delete Selected**. The **Show Routes** button displays a table of static IPv6 routes that the network usually accesses.

Advance → IPv6 → IPv6 routing → Show Routes

IP Route Table

This table shows a list of destination routes commonly accessed by your network.

Destination	Next Hop	Flags	Metric	Ref	Use	Interface
fe80::/64	::	U	256	0	0	br0
fe80::/128	::	U	0	1	0	lo
fe80::ce9d:a2ff:fedc:dc0c/128	::	U	0	1	0	lo
ff00::/8	::	U	256	2	25010	br0

Refresh Close

- *Destination* – network destination;
- *Next Hop* – next node;
- *Flags* – flags;
- *Metric* – metric;
- *Ref* – route source;

- *Use* – route usage;
- *Interface* – the interface through which the specified route is accessible.

To update the table, click **Refresh**, to close the window – **Close**.

### 6.5.9.6 IPv6 IP/Port filtering submenu. Configuring packet filtering

The page is used to configure filtering of data packets transmitted through the gateway.

*Advance* → *IPv6* → *IP/Port filtering*

**IPv6 IP/Port Filtering**

Entries in this table are used to restrict certain types of data packets through the Gateway. Use of such filters can be helpful in securing or restricting your local network.

**Outgoing Default Action**  Deny  Allow

**Incoming Default Action**  Deny  Allow

**Direction:**  **Protocol:**  **Rule Action**  Deny  Allow

**Source Interface ID:**

**Destination Interface ID:**

**Source Port:**  -

**Destination Port:**  -

**Current Filter Table:**

Select	Direction	Protocol	Source IP Address	Interface ID	Source Port Destination	IP Address	Interface ID
<input type="button" value="Delete Selected"/> <input type="button" value="Delete All"/>							

- *Outgoing Default Action Deny/Allow* – filtering of outgoing packets;
- *Incoming Default Action Deny/Allow* – filtering of incoming packets.

To save changes, click **Apply Changes**.

- *Direction* – direction of packet transmission (outgoing/incoming);
- *Protocol* – select protocol;
- *Rule Action* – packet processing policy (*Deny* – drop out; *Allow* – transmit);
- *Source Interface ID* – source interface;
- *Destination Interface ID* – destination interface;
- *Source Port*;
- *Destination Port*.

To add a filter, complete the appropriate fields and click **Add**. The added filters are displayed in **Current Filter Table**. To delete the entire table, click the **Delete All** button; to delete one filter, select it and click **Delete Selected**.

## 6.6 Diagnostics menu

The section is for diagnostics of access to various network nodes.

### 6.6.1 Ping submenu. Checking the availability of network devices

The section is designed to check the availability of network devices using the Ping utility.

#### *Diagnostics → Ping*




To check the availability of the connected device, enter its IP address in the **Host Address** field and click **Go**.

### 6.6.2 Traceroute submenu. Network diagnostics

The section is intended for network diagnostics by sending UDP packets and receiving a message about port availability/unavailability.

#### *Diagnostics → Traceroute*




To diagnose a network, you should enter an IP address of the connected device in the **Host address** field and the maximum number of hops for a packet.

### 6.6.3 System Log submenu. Logging system events

The section is intended for configuring/saving/viewing logging of system events. Logging can be disabled/enabled by selected **Disable** or **Enable**.

#### *Diagnostics → System Log*



- *Log Level* – logging level;
- *Display Level* – log display level;
- *Clear log* – clear the log.


To save the log to the local storage, click the **Save** button.

## 6.7 Admin menu

Device management section. In this menu, passwords, time, configurations and other settings are configured.


### 6.7.1 Settings submenu. Restore and reset settings

*Admin* → *Settings* → *Backup Settings*




In the section, you can copy the current settings to a file (*Backup Settings*) by clicking **Backup Settings to File**.

*Admin* → *Settings* → *Update Settings*



In the section, you can restore settings from a file that was saved earlier (update settings). Click **Choose File** to select a file, then click **Restore**.

*Admin → Settings → Restore Default*




In this section, you can reset the current settings to the factory default settings (*Restore Default*), to do this, click **Reset Settings to Default**.

**6.7.2 GPON Setting submenu. Configuring access to GPON**

In this section, you can specify a password to activate the device on OLT.

*Admin → GPON Setting*




- *PLOAM Password* – password to activate the terminal on OLT.

To save the changes, click **Apply Changes**.

### 6.7.3 Commit/Reboot submenu. Saving changes and restarting the device

Click **Commit and Reboot** to reboot the device or to save changes to the system memory. It may take several minutes to restart the device.


*Admin → Commit/Reboot*



### 6.7.4 Logout submenu. Log out the account

In the section it is possible to log out the account by clicking **Logout**.


*Admin → Logout*



### 6.7.5 Password submenu. Setting up access control (setting passwords)

In this section, you may change the password for access to the device.

*Admin → Password*




To change the password, enter the current password to the **Old Password** field, then the new password to **New Password** and to **Confirmed Password**.

To save changes, click **Apply Changes**; to reset the value, click **Reset**.

### 6.7.6 Firmware upgrade submenu. Software Update

To update the software, select the software file using the **Choose File** button and click **Upgrade**. To reset the value, use **Reset**.

*Admin → Firmware upgrade*



**⚠** During the update process, it is not allowed to turn off the device's power or restart it. The update process may take several minutes, after which the device automatically reboots.

### 6.7.7 Remote Access submenu. Configuring remote access rules

In the section it is possible to configure remote access rules using HTTP/Telnet/ICMP protocols.

*Admin → Remote Access*

Remote Access Configuration

This page is used to configure the Remote Access rules.

Enable:

Service: HTTP

Interface: LAN

IP Address: 0.0.0.0

Subnet Mask: 0.0.0.0

Port:

Add

Select	State	Interface	IP Address	Service	Port
<input type="checkbox"/>	Enable	LAN	0.0.0.0/0	ICMP	--
<input type="checkbox"/>	Enable	LAN	0.0.0.0/0	HTTP	80

Delete Selected Toggle Selected

- *Enable* – add a rule;
- *Service* – select protocol;
- *Interface* – an interface to which the rule applies;
- *IP Address* – source IP address;
- *Subnet Mask* – subnet mask;
- *Port* – destination port.

To add a rule, complete the appropriate fields and click **Add**. The added rules are displayed in **RA Table**. To activate/deactivate the selected rule, click the **Toggle selected** button. To delete one rule, select it in the column **Select** and click **Delete Selected**.

### 6.7.8 Time zone submenu. Configuring system time

In this section you may configure system time, synchronization with Internet servers of the exact time is also available.

*Admin → Time zone*

Time Zone Configuration

You can maintain the system time by synchronizing with a public time server over the Internet.

Current Time : Year 2022 Mon 1 Day 7  
Hour 6 Min 20 Sec 51

Time Zone Select : Europe/Moscow (UTC+03:00)

Enable Daylight Saving Time

Enable SNTP Client Update

WAN Interface: Any

SNTP Server :  clock.fmt.he.net  
 clock.fmt.he.net (Manual Setting)

Apply Changes Refresh

- *Current time* – current time;
- *Time Zone Select* – time zone;

- *Enable Daylight Saving Time* – daylight saving time;
- *Enable SNTP Client Update* – enable SNTP time synchronization;
- *WAN Interface* – the interface through which the time is updated;
- *SNTP Server* is the preferred time server.

To save changes, click the "Apply Changes" button, and to update the information, click the "Refresh" button.

### 6.7.9 TR-069 submenu. Configuring TR-069

The section is used to specify the data for configuring the device via TR-069.

*Admin → TR-069*

The screenshot displays the 'TR-069 Configuration' page. On the left, a navigation tree includes 'Status', 'LAN', 'WAN', 'Services', 'Advance', 'Diagnostics', 'Admin', 'Settings', 'Backup', 'Update', 'Restore Default', 'GPON Settings', 'Commit/Reboot', 'Logout', 'Password', 'Firmware Upgrade', 'Remote Access', 'Time Zone', 'TR-069', and 'Statistics'. The main panel is titled 'TR-069 Configuration' and contains the following fields and controls:

- TR069 Daemon:**  Enabled  Disabled
- EnableCWMPParamete:**  Enabled  Disabled
- ACS:**
  - URL:**
  - UserName:**
  - Password:**
  - Periodic Inform:**  Disabled  Enabled
  - Periodic Inform Interval:**
- Connection Request:**
  - UserName:**
  - Password:**
  - Path:**
  - Port:**
- Certificate Management:**
  - CPE Certificate Password:**
  - CPE Certificate:**  No file chosen
  - CA Certificate:**  No file chosen

Buttons for 'Apply' and 'Undo' are located below the Connection Request section.

- *TR069 Daemon* – enable/disable TR-069 daemon;
- *EnableCWMPParamete (Enabled/Disabled)* – permission/prohibition of CWMP settings;
- *ACS* – configuring the ACS server;
- *URL* – URL for connection;
- *UserName* – the name of the user to access the server;
- *Password* – the user's password to access the server;
- *Periodic Inform* – enabling/disabling the frequency of sending messages;
- *Periodic Inform Interval* – the time interval of sending messages.

**Connection Request** – authorization data for connecting the server to ONT.

- *UserName* – user name;
- *Password* – password for connection;
- *Path* – connection path;
- *Port* – port to connect to.

**Certificate Management** – certificate management.

- *CPE Certificate Password* – certificate password;
- *CPE Certificate* – select certificate for CPE;
- *CA Certificate* – select certificate for CA.

To save changes, click **Apply**, to reset – **Undo**.

To upload a file, click **Choose File** to select a file, then click **Upload**.

## 6.8 Statistics menu. Information about the traffic on the device ports

### 6.8.1 Interface submenu. Information about counters and errors

The section displays counters/errors in packets for each interface:

*Statistics → Interface*

Interface	Rx pkt	Rx err	Rx drop	Tx pkt	Tx err	Tx drop
LAN 1	523836	0	0	69055	0	0
LAN 2	0	0	0	0	0	0
LAN 3	0	0	0	0	0	0
LAN 4	0	0	0	0	0	0

- *Interface* – interface;
- *Rx pkt* – received packets;
- *RX err* – reception errors;
- *Rx drop* – dropped on reception;
- *Tx pkt* – packets sent;
- *Tx err* – sending error;
- *Tx drop* – dropped during transmission.

To update the data on the page, click **Refresh**.

### 6.8.2 PON submenu

The section displays counters for the optical interface:

*Statistics → PON*

PON Statistics	
Bytes Sent	58932
Bytes Received	196338
Packets Sent	330
Packets Received	1309
Unicast Packets Sent	324
Unicast Packets Received	445
Multicast Packets Sent	0
Multicast Packets Received	549
Broadcast Packets Sent	6
Broadcast Packets Received	315
FEC Errors	0
HEC Errors	0
Packets Dropped	0
Pause Packets Sent	0
Pause Packets Received	0

The following statistics are available:

- *Bytes Sent;*
- *Bytes Received;*
- *Packets Sent;*
- *Packets Received;*
- *Unicast Packet Sent;*
- *Unicast Packet Received;*
- *Multicast Packets Sent;*
- *Multicast Packets Received;*
- *Broadcast Packet Sent;*
- *Broadcast Packet Received;*
- *FEC Errors;*
- *HEC Errors;*
- *Packets Dropped;*
- *Pause Packets Sent;*
- *Pause Packets Received.*

## TECHNICAL SUPPORT

For technical assistance in issues related to handling Eltex Ltd. equipment, please, address to Service Center of the company: <https://eltex-co.com/support/>

You are welcome to visit Eltex official website to get the relevant technical documentation and software.

Official website: <https://eltex-co.com/>

Download center: <https://eltex-co.com/support/downloads/>